

LA-UR-18-23695

Approved for public release; distribution is unlimited.

Process Engineering Workshop - PT2 Machining Title:

Stephan, Elle Taylor Balog, John Arnold Author(s):

Intended for: Presentation

Issued: 2018-04-30



Process Engineering Workshop

PT-2 Machining



John Balog Elle Stephan


01/26/18



So, what do we do??

- Surveillance
 - Coupons, Samples, Disassembly
- Tooling
 - Fixturing, Tooling, Misc.
- Pit Production

Hemishells (T-Base Lathe)



Drill & Press (DMU35 Mill)




Hemishell Machining

[Similar to]
Inner Contour Fixture (U)



[Similar to]
Outer Contour Fixture (U)





Drill & Press: Manual to CNC

Switching Between Hemishell Designs

Manual



Unclassified

Stationary spindle - Need to switch fixture to accommodate various designs


Mobile spindle - No fixture change needed

CNC




Material Matters

- Microstructure of the material makes a difference
 - Density
 - Ductility
 - Hardness
 - Grain boundaries
- Alloys vs. Heat Treat vs. Annealing




Chip Formation & Surface Finish

• All at .005" depth of cut - constant speed & feed



Plutonium – the struggle is real

- Pu is very dense and very ductile like peanut butter
 - Makes it prone to smearing and tool edge build up
- Mixed waste is expensive (like \$300,000/ft³) expensive)
 - Trying to move towards dry machining to reduce costs
 - Without coolant, the chips get hotter and even more ductile → "gummy"
 - Leading to even more smearing and tool build-up









Source: LA-UR-13-20936

- Chip Accountability
 - The ergonomics of the glovebox make it difficult to recover ALL chips

Al vs. Pu





Plutonium – the struggle is real

Pu is not well understood

- Machinists rely heavily on tribal knowledge and experience to know how a material behaves - i.e. What speeds and feeds to use
- Can't practice on Pu due to limited stock, casting variations, and material constraints
 - An adequate surrogate hasn't been found
- The inability to predict the material behavior makes it difficult to standardize

But we made good parts before -- What happened??

- Before we were making loads of Pu, and machinists had ample castings to machine (read: gain experience from)
- Now There is very little Pu available for casting, and no [fresh] Pu will be made until the ER process is running again
 - All that we have has been recycled, and Pu changes over time, making each batch inconsistent, even with the same recipe
- With more hemishells to machine (aka data), we could do a process capability assessment, and better predict how the recipes machine --- but alas...

Questions?



Los Alamos National Laboratory 4/30/2018 | 9